

Mounting the BackSaver on the rear of a MN II can be a tight fit. It can be easier if you remove the back support frame from the mounting posts that adjust the height. Then mount the mounting bars to the seat poles and re-attach the frame to the mounting posts. This can all be done without any tools. Just push in the buttons and keep moving the frame up until it pops off.

The following picture shows the unit with the frame pulled off the top of the mounting posts.



After you push the mounting bars on to the poles, re-attach the frame. Make sure the cords for the strap and buckle come around the front of the front pole then back toward the frame. The strap and buckle hold the BackSaver into its mounted position. [See the illustrations on the standard \*Bucket\* installation instructions to be sure you've done it correctly \(www.cushgear.com\)](http://www.cushgear.com) .